

DESOI Snappy - Connection between round head nipple and injection connection

The DESOI Snappy is used for crack injection with polymer filler (injection resin). It safely connects the injection packer with the round head nipple M6 connection and the injection device connection and is attached to the round head nipple. The turning knuckle keeps the DESOI Snappy flexible, so that the safety bar can be adjusted downwards at any time.

The insert is suitable for all working positions, e.g. overhead work can be carried out effortlessly - WITHOUT detachment, tilting or unwanted material leaking from the packer.

DESOI Snappy

for connection round head nipple M6, hexagon AF14, turning knuckle, material connection M10x1, free passage Ø2 mm



Variant

Ø 15 x 50 mm

Nr.

16920

Advantage/Information

- The DESOI Snappy prevents uncontrolled detachment of the mouth piece from the round head nipple
- The turning knuckle can be used to bring the Snappy into the correct position (locking bar has to be at the bottom)



The DESOI Snappy is a quality product from DESOI. To ensure a long service life, the connection must be released with a rotational movement!!!

Please do not bend it!!!



Slide DESOI Snappy onto the round head nipple, locking bar at the bottom



Inject